

Prague - user guide

Setting the time

1. Pull the crown out to the second click position.
(be sure to check AM / PM is correctly set)
2. Turn the crown to set hour and minute hands.
3. Push the crown back into the normal position.


Setting the date

1. Pull out the crown to the first click position.
2. Turn the crown to alter the date setting.
3. Push the crown back into its normal position.

Note that you shouldn't set the date between the 9:00 PM and 4:00 AM time on the watch, this is because it can cause a malfunction on the timepiece. If it is necessary to set the date during that time period, first change the time to any time outside it, set the date and then reset the correct time.

Winding the mainspring

1. Place the crown in normal position.
 2. To fully wind up the watch turn the crown a minimum of 55 times.
(Be careful not to overwind your watch as this can damage the movement, if you feel resistance stop rotating the crown).
- You can fully wind up the movement by turning the ratchet wheel screw 8 times.




JACOB ZECH
ORIGINAL

Prague

- useful tips and maintenance

Congratulations on your watch!

You are now the proud owner of the Jacob Zech Prague Z1 automatic watch. We recommend this for a pleasant use: read this user guide carefully before you are going to use your Jacob Zech watch.

Specifications

- Time - hour, minutes and small second hand
- Date - the date is shown in numbers
- Vibrations - 21.600 per hour
- Deviation - between - 20 and + 40 seconds per day*
- Continuous run time - approximately 41 hours
- Movement - SEIKO NH35 automatic and manual winding movement
- Jewelry - 24 pieces

* The actual deviation per day may, due to the properties of mechanical watches and conditions of use (eg the time frame that the watch is worn on the wrist, the ambient temperature, arm movements, whether the spring is fully wound or not, etc.), fall outside it specified accuracy range.

Water-resistant (5 bar, 50m. WR)

The Jacob Zech Prague Z1 watch has a water resistance of 5 bar.

- The watch is suitable for showering.
- We do not recommend swimming with the watch.
- The watch is NOT suitable for diving.

To preserve the quality of the watch, we advise to never let the watch come into contact with water or other liquids.

Important! A pressure value in bar is a test pressure value and should not be considered a pressure at actual dive depth, as swimming movements and temperature differences can increase the pressure at a given depth.


JACOB ZECH
ORIGINAL

Prague

- useful tips and maintenance

Maintain the quality of your watch

The watch case and strap are in direct contact with the skin. Keep the case and strap clean at all times to make the watch last longer and reduce the risk of skin irritation.

Immediately clean your watch with a soft, dry cloth when you take it off. This makes the watch case, watch strap and gasket last longer.

Leather strap - Gently dab the moisture with a soft, dry cloth. Do not rub the leather as this can cause wear or discoloration.

Stainless steel bracelet - Clean the strap with a soft toothbrush, and clean water or water with a little soap. Do not allow water to get on the watch case.

Rash and allergic reactions

Adjust the watch strap so that there is space between your wrist and the strap so that air can flow through it.

Persistent and/or repeated contact with the watch strap can cause skin irritation or inflammation in people who are sensitive to it.

Possible causes of skin inflammation are:

- Allergic reaction to steel or leather
- Rust, dirt, or perspiration on the watch case or strap.

In case of allergy symptoms or skin irritation, stop wearing the watch immediately, and consult a physician.